ATARIWRITER 1027 SUPPLEMENT

Here is some valuable information on the 1027 functioning with AtariWriter:

The default values for the left and right margins will give you very wide margins. To adjust them, try setting the left margin at 0 and the right at 80.

Choose printer option #1 when using Print Preview and when printing a file.

To underline, type a CONTROL-O (CONTROL key and the letter O at the same time) followed immediately by the number 15. To end underlining, type CONTROL-O followed by a 14. Always be sure to end the document with a carriage return. Special variations of these instructions are:

When the text to be underlined begins with a number, use the number 015 instead of 15 to begin.

When the text to be underlined extends beyond the line (i.e. the printer performs a carriage return) your line will extend into the left margin unless you

- go to Print Preview (see pg. 23 in your AW manual) and see where the line will be broken, and ...
- stop and then start the underlining at that point (i.e. type CONTROL-O 15CONTROL-O 14).

To make the printer stop at the end of a page so you can insert another one, type CONTROL-W immediately under the format block at the beginning of the document. When you insert the next page, simply press RETURN, as prompted.

Occasionally the printer will "time out" when printing. This occurs randomly and should not occur often. When it happens you have two choices;

1) You may wait it out. After 4½ minutes, the printer will resume where it left off.

2) You may press the BREAK key and reprint, starting with that page.

The apostrophe is SHIFT-7. Yes, that really is it. It's just a little odd.

If you have further questions or comments, feel free to write or call (408)745-4851.